



STEP #1

APPROVED DRYVIT/TREMCO FLASHING MATERIAL (SEE NOTE 1)
 APPROVED DRYVIT/TREMCO AIR/WATER-RESISTIVE BARRIER COATING (SEE NOTE 1)




STEP #2

APPROVED DRYVIT/TREMCO FLASHING MATERIAL (SEE NOTES 1, 2, AND 3)




STEP #3

INSTALL DIAGONAL STRIP OF APPROVED DRYVIT/TREMCO FLASHING MATERIAL AT CORNERS (SEE NOTES 1, 2, AND 3)



STEP #4

INSTALL APPROVED DRYVIT/TREMCO FLASHING MATERIAL AT JAMBS (SEE NOTES 1, 2, AND 3)



STEP #5

INSTALL APPROVED DRYVIT/TREMCO FLASHING MATERIAL AT HEAD (SEE NOTES 1, 2, AND 3)

Rough Opening Preparation⁴

NOTES:

1. Refer to Dryvit publication DS840 for AWRB and flashing application.
2. Approved Dryvit/Tremco flashing material shall extend to interior face of opening.
3. Install window unit and associated flashings per manufacturer's recommendations, code requirements and project documents.
4. Refer to head, sill and jamb details for flashing integration.

The architecture, engineering, and design of the project using the Dryvit products is the responsibility of the project's design professional. All systems must comply with local building codes and standards. This detail is for general information and guidance only and Dryvit specifically disclaims any liability for the use of this detail and for the architecture, design, engineering or workmanship of any project. The project design professional determines, in its sole discretion, whether this detail or a functionally equivalent detail is best suited for the project. Use of a functionally equivalent detail does not violate Dryvit's warranty. This detail is subject to change without notice. Contact Dryvit to ensure you have the most recent version.



One Energy Way, West Warwick, RI 02893
 Phone : 800-556-7752